

# **WCDMA&LTE** Android RIL Driver User Guide

**UMTS/HSPA/LTE Module Series**

Rev. WCDMA&LTE\_Android\_RIL\_Driver\_User\_Guide\_V1.2

Date: 2015-04-07



**Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:**

**Quectel Wireless Solutions Co., Ltd.**

Office 501, Building 13, No.99, Tianzhou Road, Shanghai, China, 200233

Tel: +86 21 5108 6236

Mail: [info@quectel.com](mailto:info@quectel.com)

**Or our local office, for more information, please visit:**

<http://www.quectel.com/support/salesupport.aspx>

**For technical support, to report documentation errors, please visit:**

<http://www.quectel.com/support/techsupport.aspx>

Or Email: [Support@quectel.com](mailto:Support@quectel.com)

**GENERAL NOTES**

QUECTEL OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

**COPYRIGHT**

THIS INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTABLE, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THIS CONTENTS ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

***Copyright © Quectel Wireless Solutions Co., Ltd. 2015. All rights reserved.***

# About the Document

## History

Revision	Date	Author	Description
1.0	2015-02-27	Carl YIN	Initial
1.1	2015-03-25	Carl YIN	Updated supported products
1.2	2015-04-07	Kent XU	Added Zero Packet feature in Section 3.2.4.

## Contents

About the Document.....	2
Contents .....	3
Table Index.....	4
<b>1 Introduction .....</b>	<b>5</b>
1.1. Directory Structure .....	5
<b>2 Overview of Android RIL Driver .....</b>	<b>6</b>
2.1. Supported Products .....	6
2.2. Supported Functions.....	6
2.3. Supported Android Versions .....	7
<b>3 RIL Integration.....</b>	<b>8</b>
3.1. RIL Driver Structure.....	8
3.2. Kernel Configuration .....	9
3.2.1. USB Driver Configuration for UC15/UC20/EC20.....	9
3.2.2. USB Driver Configuration for UGxx .....	10
3.2.3. PPP Kernel Configuration .....	10
3.2.4. Add the Zero Packet Mechanism.....	10
3.2.4.1. Zero Packet Mechanism for UC15/UC20/EC20.....	10
3.2.4.2. Zero Packet Mechanism for UGxx .....	11
3.3. RIL Driver Integration .....	12
3.4. System Configuration.....	13
3.4.1. "init.rc" Configuration.....	13
3.4.2. Modifying the Right of RILD .....	14
<b>4 Debugging Method .....</b>	<b>15</b>
4.1. Method of Catching LOG .....	15
4.2. Some Common LOG Tags.....	15
<b>5 Appendix A Reference.....</b>	<b>16</b>

## Table Index

TABLE 1: SUPPORTED PRODUCTS .....	6
TABLE 2: SUPPORTED FUNCTIONS .....	6
TABLE 3: SUPPORTED ANDROID VERSIONS .....	7
TABLE 4: TERMS AND ABBREVIATIONS .....	16

Quectel  
Confidential

# 1 Introduction

This document mainly introduces how to integrate RIL Driver into Android OS of your target machine and how to modify the configuration files for starting RIL service and PPP dialling.

## 1.1. Directory Structure

The file structure of Quectel RIL Driver Package:

- |— Android.mk
- |— atchannel.c
- |— atchannel.h
- |— at\_tok.c
- |— at\_tok.h
- |— misc.c
- |— misc.h
- |— ql-pppd.c
- |— quectel\_ril\_porting\_guide.txt
- |— reference-ril.c

## 2 Overview of Android RIL Driver

### 2.1. Supported Products

Table 1: Supported Products

Product	Support or Not
UC20	YES
UC15	YES
UGxx	YES
EC20	YES

### 2.2. Supported Functions

Table 2: Supported Functions

Function	Support or Not
SMS	YES
VOICE CALL	YES
DATA SERVICE	YES
SIM TOOL KIT	NO
PHONEBOOK	YES

## 2.3. Supported Android Versions

At present, Quectel RIL driver supports the following Android versions:

**Table 3: Supported Android Versions**

Versions	Support or not
Android 2.x	YES
Android 3.x	YES
Android 4.x	YES



## 3 RIL Integration

The first part describes the RIL driver architecture. The rest introduces how to set up Android system with the RIL driver.

### 3.1. RIL Driver Structure

Android RIL (Radio Interface Layer) provides the abstract layer between Telephony service and Radio hardware.

The following illustration describes the RIL's position in the Android architecture.




Figure 1: RIL Driver Architecture

The RIL in Android is located between Kernel and Application Framework. It is divided into two parts, one is RILD and the other is Vendor RIL.

RILD is responsible for the communication between Socket and Application Framework.

Vendor RIL is responsible for communication with Radio via AT command channel and Packet data channel (PDCH). AT command channel is used for communicating with Radio directly and PDCH used for data service.

The java framework of RIL is divided into two parts too. One is RIL module and the other is Phone module. The RIL module is used to communicate with the lower RILD. The Phone module directly provides phone function interfaces to application through which you can call to realize the phone functions.

## 3.2. Kernel Configuration

You need to configure the kernel to support the UC15/UC20/UGxx/EC20 modules and connect it to the applicable interface.

There are several mandatory selected items in kernel configuration, you should follow the steps below to configure the kernel:

Step 1:

```
cd <your kernel directory>
```

Step 2:

```
make menuconfig
```

### 3.2.1. USB Driver Configuration for UC15/UC20/EC20

```
[*]Device Drivers →  
    [*]USB Support →  
        [*]USB Serial Converter support →  
            [*]USB driver for GSM and CDMA modems
```

Add UC15/UC20/EC20's Vendor ID and Product ID in "option\_ids[]" in the file "drivers/usb/serial/option.c":

```
static const struct usb_device_id option_ids[] = {  
    { USB_DEVICE(0x05C6, 0x9090) }, //For UC15  
    { USB_DEVICE(0x05C6, 0x9003) }, //For UC20
```

```
{ USB_DEVICE(0x05C6, 0x9215) }, //For EC20
```

### 3.2.2. USB Driver Configuration for UGxx

```
[*]Device Drivers →
```

```
  [*]USB Support →
```

```
    [*]USB Modem (CDC ACM) support
```

### 3.2.3. PPP Kernel Configuration

```
Device Drivers --->
```

```
  [*] Network device support --->
```

```
    <*> PPP (point-to-point protocol) support
```

```
    <*> PPP support for async serial ports
```

```
    <*> PPP support for sync tty ports
```

```
    <*> PPP Deflate compression
```

### 3.2.4. Add the Zero Packet Mechanism

#### 3.2.4.1. Zero Packet Mechanism for UC15/UC20/EC20

As required by the USB protocol, you need to add the mechanism for processing zero packets during transmission of “usb\_wwan.c” file under “[KERNEL]/drivers/usb/serial”.

However, zero packet mechanism is valid for **Linux 2.6.35** or **later** versions. This document takes the **Linux 3.2** as an example, the other versions could be a bit different, but it is basically the same.

You need to add the following statements to the “usb\_wwan\_setup\_urb” function, as shown below:

```
static struct urb *usb_wwan_setup_urb(struct usb_serial *serial, int endpoint,
                                     int dir, void *ctx, char *buf, int len, void (*callback) (struct urb *))
{
    struct urb *urb;

    if (endpoint == -1)
        return NULL;    /* endpoint not needed */

    urb = usb_alloc_urb(0, GFP_KERNEL);    /* No ISO */

    if (urb == NULL) {
```

```

        dbg("%s: alloc for endpoint %d failed.", __func__, endpoint);

        return NULL;
    }

    /* Fill URB using supplied data. */
    usb_fill_bulk_urb(urb, serial->dev,

        usb_sndbulkpipe(serial->dev, endpoint) | dir,

        buf, len, callback, ctx);

    #if 1 // Added by Quectel for Zero Packet
    if (dir == USB_DIR_OUT) {

        struct usb_device_descriptor *desc = &serial->dev->descriptor;

        if (desc->idVendor == 0x05C6 && (desc->idProduct == 0x9003 || desc->idProduct ==
0x9090 || desc->idProduct == 0x9215))

            urb->transfer_flags |= URB_ZERO_PACKET;

    }

    #end

    return urb;
}

```

#### 3.2.4.2. Zero Packet Mechanism for UGxx

As required by the USB protocol, you need to add the mechanism for processing zero packets during transmission of “cdc-acm.c” file under “[KERNEL]/drivers/usb/class”.

This document takes the **Linux 3.2** as an example, the other versions could be a bit different, but it is basically the same.

You need to add the following statements to the “**acm\_probe**” function, as shown below:

```

.....
for (i = 0; i < ACM_NW; i++) {

    struct acm_wb *snd = &(acm->wb[i]);

    snd->urb = usb_alloc_urb(0, GFP_KERNEL);

    if (snd->urb == NULL) {

        dev_err(&intf->dev,

```

```
        "out of memory (write urbs usb_alloc_urb)\n");
    goto alloc_fail7;
}
if (usb_endpoint_xfer_int(epwrite))
    usb_fill_int_urb(snd->urb, usb_dev,
        usb_sndbulkpipe(usb_dev, epwrite->bEndpointAddress),
        NULL, acm->writsize, acm_write_bulk, snd, epwrite->bInterval);
else
    usb_fill_bulk_urb(snd->urb, usb_dev,
        usb_sndbulkpipe(usb_dev, epwrite->bEndpointAddress),
        NULL, acm->writsize, acm_write_bulk, snd);
snd->urb->transfer_flags |= URB_NO_TRANSFER_DMA_MAP;
#if 1 // Added by Quectel for Zero Packet
if (usb_dev->descriptor.idVendor == 0x1519 && usb_dev->descriptor.idProduct == 0x0020)
    snd->urb->transfer_flags |= URB_ZERO_PACKET;
#endif
snd->instance = acm;
}
usb_set_intfdata(intf,acm)
.....
```

### 3.3. RIL Driver Integration

At present, Quectel provides RIL driver in the form of source code. You only need to copy the RIL driver source code files to the correct path on your project directory, and recompile the Android system.

The source path of the RIL driver files in RIL Driver package is:

***Driver package/reference-ril***

The destination path in Android system is:

***(\$Android\_src)/hardware/ril/***

After you recompile the Android system successfully, there are four files in folder "out/target/product/(\$your\_board\_name)/system" which is generated by Quectel RIL:

- lib/libreference-ril.so
- etc/ppp/init.quectel-pppd
- etc/ppp/ip-up
- etc/ppp/ip-down

### 3.4. System Configuration

In order to use the RIL driver normally, you also have to modify some Android system configuration files.

#### 3.4.1. "init.rc" Configuration

Add service "ril-daemon" and service "pppd\_gprs" in "init.rc":

```
service ril-daemon /system/bin/rild -l /system/lib/libreference-ril.so
    class main
    socket rild stream 660 root radio
    socket rild-debug stream 666 radio system
    user root
    group radio cache inet misc audio sdcard_rw log
```

```
service quectel-pppd /etc/ppp/init.quectel-pppd
    class main
    user root
    group radio cache inet misc log
    disabled
    oneshot
```

The "init.rc" file may be located in different paths according to different projects, for example:

- system/core/rootdir/init.rc
- device/fsl/imx6/init.rc
- device/ti/am335xevm\_sk/init.am335xevm.rc
- device/generic/x86/init.rc
- device/samsung/smdkv210/init.smdkv210\_sdmmc.rc

### 3.4.2. Modifying the Right of RILD

RILD (ril-daemon) requires root privilege. So you need to comment out the function **switchUser()** in the file "(\$Android\_src)/hardware/ril/rild/rild.c":

```
OpenLib:
#endif
//switchUser();

dlHandle = dlopen(rilLibPath, RTLD_NOW)
```

Quectel  
Confidential

# 4 Debugging Method

## 4.1. Method of Catching LOG

- 1) Catch the log of RIL module by typing the following commands in window's CMD tool:

```
adb logcat -b radio -v time
```

- 2) Catch the log of Android system by typing the following commands in window's CMD tool:

```
adb logcat -v time
```

- 3) Sometimes, you want to make tests on lots of devices or for long time, it is not convenient to connect all devices with PC via USB cables. You can log file by next commands:

```
adb logcat -b radio -v time -f <filename> &
```

The char '&' makes the 'logcat' process running in background, so you can disconnect your devices.

- 4) When you finish your tests, you can fetch log files from devices to local directory by next commands:

```
adb pull <filename> <local directory>
```

## 4.2. Some Common LOG Tags

<b>RIL</b>	/hardware/ril/reference-ril/refereince-ril.c
<b>AT</b>	/hardware/ril/reference-ril/atchannel.c
<b>RILD</b>	/hardware/ril/rild/rild.c
<b>RILC</b>	/hardware/ril/libril/ril.cpp
<b>RILB</b>	/frameworks/base/telephony/java/com/android/internal/telephony/BaseCommands.java
<b>RILJ</b>	/frameworks/base/telephony/java/com/android/internal/telephony/gsm/RIL.java
<b>GSM</b>	/frameworks/base/telephony/java/com/android/internal/telephony/gsm/GSMPhone.java



# 5 Appendix A Reference

Table 4: Terms and Abbreviations

Abbreviation	Description
RIL	Radio Interface Layer
TA	Terminal Adapter
MS	Mobile Station
GSM	Global System for Mobile Communications
WCDMA	Wideband Code Division Multiple Access
VID	Vendor ID
PID	Product ID